

Install and configure Hyper-V and WDS in Server -2019-15

Introduction

- **Hyper-V** is Microsoft's virtualization platform. It allows you to create and run multiple virtual machines (VMs) on a single physical server. This helps in resource optimization, testing environments, and server consolidation.
- **WDS (Windows Deployment Services)** is a role that enables administrators to deploy Windows operating systems over the network. With WDS, client machines can boot via PXE (Preboot Execution Environment) and install Windows without requiring physical media.

Hyper-V and WDS together are useful in enterprise environments where multiple virtual or physical machines need to be quickly set up and managed.

Steps to Install and Configure Hyper-V

Step 1: Install Hyper-V Role

1. Open **Server Manager**.
2. Click **Add Roles and Features**.
3. Select **Role-based or feature-based installation**.
4. Choose your server.
5. Select **Hyper-V** and complete the installation.
6. Restart the server if prompted.

Step 2: Configure Hyper-V

1. Open **Hyper-V Manager** from **Tools** in Server Manager.
2. Configure **Virtual Switch**:
 - In Hyper-V Manager, go to **Virtual Switch Manager**.
 - Create a new **External switch** if you want VMs to access the network and internet.
3. Create a Virtual Machine:
 - In Hyper-V Manager, right-click server name → **New → Virtual Machine**.
 - Set name and location.

- Assign memory (e.g., 2048 MB).
- Connect to the Virtual Switch created.
- Create a virtual hard disk (VHDX).
- Mount an ISO file of Windows to install the OS.
- Finish and start the VM.

Steps to Install and Configure WDS

Step 1: Install WDS Role

1. Open **Server Manager**.
2. Click **Add Roles and Features**.
3. Select **Windows Deployment Services**.
4. Choose both **Deployment Server** and **Transport Server**.
5. Complete installation.

Step 2: Configure WDS

1. Open **WDS Management Console** from **Tools**.
2. Right-click the server → **Configure Server**.
3. Choose **Integrated with Active Directory** (recommended for domain environments).
4. Specify a folder path to store images (e.g., D:\RemoteInstall).
5. Configure PXE response settings (Respond to all clients or known clients only).

Step 3: Add Boot and Install Images

1. Insert a Windows Server or Windows 10 ISO into the server.
2. In WDS console, right-click **Boot Images** → **Add Boot Image**.
 - Browse to sources\boot.wim on the ISO.
3. Right-click **Install Images** → **Add Install Image**.
 - Create a new image group (e.g., "Windows 10").
 - Browse to sources\install.wim from the ISO.


Step 4: Configure Client PXE Boot

1. Ensure client machine (physical or virtual) is set to **boot from network (PXE)**.

2. Start client, press **F12** to PXE boot.
3. WDS will provide the boot image.
4. Select install image, and Windows installation will begin over the network.

We'll see how to install a server on network

1. Assumed the host machine (it can be a Windows 10 laptop) is connecting to Corporate Network, so the WDS VM and testing VM will get the IP address from DHCP server. if it's at your lab or pilot environment, you need to build your own DHCP server.
2. Login to WDS2019 Server via local Administrator (WDS server can be a domain member server or WORKGROUP server)
3. Use ping command to make sure the VM (WDS2019) can ping outside network.




```
Administrator: Windows PowerShell
Windows PowerShell
Copyright (C) Microsoft Corporation. All rights reserved.

PS C:\Users\Administrator> ping 8.8.8.8


Pinging 8.8.8.8 with 32 bytes of data:
Reply from 8.8.8.8: bytes=32 time=11ms TTL=51
Reply from 8.8.8.8: bytes=32 time=6ms TTL=51
Reply from 8.8.8.8: bytes=32 time=8ms TTL=51
Reply from 8.8.8.8: bytes=32 time=6ms TTL=51

Ping statistics for 8.8.8.8:
    Packets: Sent = 4, Received = 4, Lost = 0 (0% loss),
    Approximate round trip times in milli-seconds:
        Minimum = 6ms, Maximum = 11ms, Average = 7ms
PS C:\Users\Administrator>
```


4. On the Server Manager page, select Manage, click Add Roles and Features.




5. On the Before you begin page, click Next.




6. On the Select installation type page, select Role-based or feature-based installation, click Next.




7. On the Select destination server page, click Next.




8. On the Select server roles page, select Windows Deployment Services.




9. On the Add features that are required for Windows Deployment Services page, click Add Features.




10. On the Select server roles page, click Next.




11. On the Select features page, click Next.




12. On the WDS page, click Next.




13. On the Select role services page, click Next.




14. On the Confirm installation selections page, select Restart the destination server automatically if required, click Yes on the Add Roles and Feature wizard warning message, and then click Install.




15. On the Installation progress page, click Close.




16. On the Server Manager, select Tools, click Windows Deployment Services.




17. On the Windows Deployment Services page, expand Servers, right-click the WDS2019 server and then select Configure Server.




18. On the Before You Begin page, click Next.




19. On the Install Options page, select Standalone server, click Next.




20. On the Remote Installation Folder Location page, click Next. (You also can select the folder is not the same as system volume).




21. On the System Volume Warning message, click Yes.




22. On the PXE Server Initial Settings page, select Response to all client computers (known and unknown), click Next.




23. On the Operation Complete page, unselect Add images to the server now, click Finish.




24. Creating a new folder at WDS2019 server and copy boot.wim and install.wim of D:\sources to this folder. (D drive is mounting Windows Server 2019 ISO image).




25. On the Windows Deployment Services page, expand WDS2019 and right click Boot Images, click Add Boot Image.




26. On the Image file page, click Browse at File location.



27. Select boot.wim file, click Open.



28. On Image File page, click Next.



29. On the Image Metadata page, type Image name and description for the Boot Image, click Next.

The screenshot shows the 'Add Image Wizard' window with the 'Image Metadata' tab selected. The window title is 'Add Image Wizard'. The tab is 'Image Metadata'. The text says 'Enter a name and description for the following image: 'Microsoft Windows Setup (x64)'. Below this, there are three fields: 'Image name:' with the value 'Microsoft Windows Server 2019 (x64)', 'Image description:' with the value 'Microsoft Windows Server 2019 (x64)', and 'Image architecture:' with the value 'x64'. At the bottom, there are three buttons: '< Back', 'Next >', and 'Cancel'. The 'Next >' button is highlighted with a blue border.

Add Image Wizard

Image Metadata

Enter a name and description for the following image:
'Microsoft Windows Setup (x64)'

Image name:
Microsoft Windows Server 2019 (x64)

Image description:
Microsoft Windows Server 2019 (x64)

Image architecture:
x64

< Back Next > Cancel

30. Click Next on the Summary page.

The screenshot shows the 'Add Image Wizard' window with the 'Summary' tab selected. The window title is 'Add Image Wizard'. The tab is 'Summary'. The text says 'You have selected the following images'. Below this, there are two fields: 'Image group:' with the value 'Boot Images' and 'Image file:' with the value 'C:\Windows Server 2019 Images\boot.wim'. Below these, there is a section titled 'Selected images:' with a list box containing one item: 'Microsoft Windows Server 2019 (x64)'. At the bottom, there is a message: 'To change your selection, click Back. To add the selected images to the server, click Next.' and three buttons: '< Back', 'Next >', and 'Cancel'. The 'Next >' button is highlighted with a blue border.

Add Image Wizard

Summary

You have selected the following images

Image group: Boot Images

Image file: C:\Windows Server 2019 Images\boot.wim


Selected images:

Name
Microsoft Windows Server 2019 (x64)


To change your selection, click Back. To add the selected images to the server, click Next.

< Back Next > Cancel


31. On the Task Progress page, make sure the operation is complete without issues, click Finish.



32. On the Windows Deployment Services page, expand WDS2019 server, right-click Install Images, click Add Install Image.



33. On the Image Group, type image group name, click Next.



34. On the Image File page, click Browse from File location

35. Select install.wim file and click Open.

36. On the Image File page, click Next.


The screenshot shows the 'Add Image Wizard' window, specifically the 'Image File' step. The window title is 'Add Image Wizard' with a close button (X) in the top right corner. Below the title bar, there is a sub-header 'Image File' and a small icon of a box with a plus sign and a CD. The main area contains the instruction: 'Enter the location of the Windows image file that contains the images to add.' Below this, there is a 'File location:' label followed by a text input field containing 'C:\Windows Server 2019 Images\install.wim' and a 'Browse...' button. A note states: 'Note: The default boot and install images (Boot.wim and Install.wim) are located on the installation DVD in the \Sources folder.' Below the note is a blue hyperlink: 'More information about images and image types'. At the bottom, there are three buttons: '< Back', 'Next >' (which is highlighted with a blue border), and 'Cancel'.

37. On the Available Images, select Windows Server 2019 SERVERSTANDARD and Windows Server 2019 SERVERDATAcenter, click Next.

The screenshot shows the 'Add Image Wizard' window, specifically the 'Available Images' step. The window title is 'Add Image Wizard' with a close button (X) in the top right corner. Below the title bar, there is a sub-header 'Available Images' and a small icon of a box with a plus sign and a CD. The main area contains the instruction: 'The file that you specified contains the following images. Select the images that you want to add to the server.' Below this is a table with three columns: 'Name', 'Architecture', and 'Description'. The table lists four Windows Server 2019 images. The second row, 'Windows Server 2019 SERVERSTANDARD', is selected with a checkmark. Below the table is a horizontal scrollbar. At the bottom, there is a checkbox labeled 'Use the default name and description for each of the selected images' which is checked. At the very bottom, there are three buttons: '< Back', 'Next >' (which is highlighted with a blue border), and 'Cancel'.

Name	Architecture	Description
☐ Windows Server 2019 SERVERSTANDARDCORE	x64	Windows S
☒ Windows Server 2019 SERVERSTANDARD	x64	Windows S
☐ Windows Server 2019 SERVERDATACENTERCORE	x64	Windows S
☐ Windows Server 2019 SERVERDATACENTER	x64	Windows S


38. On the Summary page, click Next.



39. On the Task Progress page, make sure the operation is complete without issues, click Finish.

40. Now, we can try to deploy windows server 2019 via PXE to another VM and test WDS functions.

41. On the Hyper-V Manager page, on the Actions pane, click New and select Virtual Machine.




42. On the Before You Begin page, click Next.

43. On the Specify Name and Location page, type Name and select location for the test Virtual Machine, click Next.


44. On the Specify Generation page, select Generation 2, click Next.

45. On the Assign Memory page, assign 4GB for Startup memory, click Next.


46. On the Configure Networking page, select External Network at Connection, click Next.




47. On the Connect Virtual Hard Disk page, click Next.




48. On the Installation Options page, select Installation an operating system from a network-based installation server, click Next.




49. On the Completing the New Virtual Machine Wizard page, click Finish.



50. On the Hyper-V Manager page, right-click Test virtual machine and select Connect.




51. On the Test Virtual Machine console, click Start.




52. Press Enter for the network boot service.



53. It will start loading boot image file from WDS Server.



54. After loading image file completed, on the Locate and Keyboard page, click Next.



55. Type local administrator and password to connect to WDS2019 server.

56. Select the Operating system you would like to install, click Next.